

## C-Track Festooning Installation Instructions for Jibs with W12 - W27 Beams

- Using Unistrut Nuts (4BAR-120), bolt C-Track Hangers (06000) to Unistrut Brackets (06020). Make sure the hangers are installed at a consistent distance from the end of each bracket.
- Mount assembled brackets to beam with supplied hardware (Items 10, 11, & 12) utilizing pre-drilled holes in the beam web.
- Slide the C-Track (06008 or 06009) into the hangers. Start at one end of the system. Install Track Coupler (06001) (if required) as you proceed, as it will support the adjacent section of track. After all track and hangers are in place, tighten hanger retaining hardware.
- Install a Flat Cable End Clamp (06003) on the mast end of the C-Track.
- Install selected number of Cable Trolleys (06004) into the C-Track. If it is convenient, cable may be installed into trolleys on the floor, establishing the correct loops and tie wrapping as required.
- Install the Towing Trolley (06005) into the C-Track. This may also be assembled on the floor, if convenient.  
*Alternate: Mount all trolleys for one side in one length of track. Assemble cable to trolleys, lift into place.*
- Install a Hanger Endstop (06002) on the open end of the C-Track.
- Remove any extra track with a fine tooth hacksaw.
- Connect cables to junction box or enclosure as needed.

ITEM	Partnumber	DESCRIPTION
1	06000	C-TRACK HANGER
2	06001	COUPLER W/ HDW
3	06002	HANGER ENDSTOP
4	06003	FLAT CABLE END CLAMP
5	06004	FLAT CABLE TROLLEY
6	06005	FLAT CABLE TOW TROLLEY
7	06008 / 06009	C-TRACK, 13' OR 20'
8	06020	UNISTRUT BRACKET, 18"
9	0-79083-100	UNISTRUT NUT, 3/8"-16
10	02026	HHCS 1-2"-13 X 1.5" LG
11	03291	LOCKWASHER 1/2"
12	03289	HEXNUT 1/2"-13, ZNPL
13	VARIABLES	FLAT CABLE TO HOIST
14	VARIABLES	JIB BOOM

